

SENSIT® HXG-3

Combustible Gas Detector INSTRUCTION MANUAL

Read and understand
instructions before use.



Approved UL913, For Class 1,
Division 1, Groups C & D
hazardous locations when used
with alkaline batteries.

Warning:
*To prevent ignition
of flammable or
combustible
atmospheres,
disconnect power
before servicing.*



CONTENTS

- Page # 1. Accessories and Parts
2. General Description
2. Specifications
3. Product Features
5. Sensor Type
5. Battery Installation
6. Adjustable Features - Factory Only
7. Operation and Use
10. Calibration Check
11. Menu
16. Calibration
18. Warranty and Repair Policy

ACCESSORIES AND PARTS

Standard Accessories (included)

Carrying Case	872-00001	Wrist Strap	360-00040
Filter Cap	365-00045		
Instruction Manual	750-00023	Alkaline Batteries	310-00004

Optional Accessories and Parts

Extension Adapter	870-00012
Printer	870-00004
PC Interface with Software	870-00008
Calibration Kit – Methane	881-00015
Calibration Kit – Pentane	881-00077
LEL Sensor	375-2611-01

NOTICE



CAUTION

This safety symbol is used to indicate a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.

GENERAL DESCRIPTION

The **Sensit® HXG-3** is designed to detect combustible gases. All **Sensit® HXG-3** instruments incorporate an advanced low power semiconductor sensor to measure combustible gases in LEL (Lower Explosive Limit) range. All measurements are in 0.1% LEL increments. The ppm display is simultaneously shown in 1 or 10ppm increments (resolution). An automatically backlit display shows all gas concentrations being measured. LEDs located on the front of the instrument indicate preset visual warnings of increased gas concentration.

Audible and visual alarms warn the operator of hazardous conditions being sensed. The preset alarms are indicated by a red flashing LED, display indicator and alarm sound. The combustible gas alarm is preset from 50% LEL (2.5% methane or 0.75% pentane).

The **Sensit® HXG-3** instrument is approved by Underwriters Laboratories to UL913, for Class 1, Division 1, Groups C & D hazardous locations when used with *Duracell™* MN1400BK or equivalent alkaline batteries.

SPECIFICATIONS

SENSOR SPECIFICATIONS

TYPE	RESOLUTION	RANGE	ACCURACY
Leak	1ppm or 10ppm	0-50,000ppm	±10%
LEL	0.1%	0-100%	±10%

PRODUCT SPECIFICATIONS

Size:	11.5" x 3" x 2.32" (292 x 76 x 69 mm)
Weight:	1.2 lbs.
Operational Temp:	0 to 120° F
Storage Temp:	-20° to 132° F
Battery Life-Alkaline:	approximately 25 hrs. continuous

PRODUCT FEATURES



Sensit® HXG-3 instruments are constructed of durable ABS plastic to withstand the rigors of field use.

Incorporated in the hand grip area is the battery compartment. All **Sensit® HXG-3** instruments require 3 "C" type alkaline batteries. *Duracell MN 1400* batteries provide approximately 25 hours of continuous use. A thumbwheel is located on the right side of the instrument to activate the audible tick sound that helps in locating the source of a gas leak. This tick is generated by using specialized circuitry in combination with the LEL sensor located at the end of the gooseneck assembly.

PRODUCT FEATURES *continued from page 3*

The tick can be easily heard with the speaker located in the back of the instrument.

The Infrared Communication window is located on the right side to allow the **Sensit® HXG-3** instrument to download: Calibration data; Communicate with Smart-Cal Calibration Station; PCI-2s Computer Interface; Readings the operator has elected to save to the instrument's on-board memory.

A flexible gooseneck is used to assist in locating the source of gas leaks and remote sampling.

A two line display continuously updates the operator of all available gas concentrations and alarms simultaneously as well as indicates battery power. Below the display is a series of LEDs that are preset to indicate combustible gas concentrations. During an alarm condition the red LED on the right side will flash and an audible warning will sound.

There are 3 operational button pads on the front of all **Sensit® HXG-3** instruments.

- **POWER/MUTE BUTTON (A):** Operate the POWER and MUTE feature and exit menu items.
- **MENU BUTTON (B):** Use to enter, change and select menu items.
- **SAVE/ZERO BUTTON (C):** Use save data feature, zero sensor, scroll and change menu items.

SENSOR TYPE

Combustible Gas Sensor

All **Sensit® HXG-3** instruments incorporate a highly sensitive semiconductor type sensor. The function and accuracy of the sensor are monitored and controlled by specialized circuitry and a microprocessor. This sensor is capable of measuring concentrations of 10ppm of methane (natural) gas up to 100% LEL.

BATTERY INSTALLATION/REPLACEMENT

⚠ CAUTION: Always change batteries in an environment free of combustible gases.

Battery replacement is necessary when the display reads **BAT LOW**, an audible alarm sounds and the green ready LED flashes. When the instrument remains in **BAT LOW**, a countdown will appear starting at 300 seconds (5 minutes) which is the maximum time remaining to shutdown.

Remove the battery sleeve cover by depressing the locking tab on the front of the handle with a coin or flat object and pulling the handle away from the top or display area of the instrument.

Place 3 approved batteries into the battery holder. For best results hold the battery compartment so that it lays in your right hand. With your left hand install the battery that goes toward the front first, the battery that is in contact with the rear spring second and finally insert the third battery in the center by forcing the second battery such that the spring compresses and allows the batteries to go into place.

BATTERY INSTALLATION/REPLACEMENT *Continued from pg 5*

If you do not use your right hand to hold the bottom of the battery compartment the batteries can come out. Observe the polarity markings on the inside of the battery holder. Improper installation will cause the instrument not to operate. Replace the battery sleeve and allow the locking tab to snap into position.

NOTE: Improper battery installation will disable the instrument.

Check to be sure the handle is secure to the instrument body by gently pulling the handle away. The handle will remain firmly in place if a proper connection is made.

ADJUSTABLE FEATURES (FACTORY ONLY)

<i>MENU ITEMS</i>	<i>RANGE</i>	<i>DEFAULT</i>
Session Saves	1-100	6
Alarm-LEL	0-100%	50%
PPM Display Option	1ppm or 10ppm	10ppm
Cal Due Interval	30, 45, 60, 90, 180, 360	30 days
Show Session Log*	1-100	6
Warm-up Time	10-30 sec.	30 sec.
Purge Time	1-60 sec.	0 sec.

* Can be disabled

⚠ CAUTION: Always start any Sensit® HXG-3 in a gas free environment to insure a proper zero.

1. Push and hold the power button (A) until the display illuminates.
2. If the display fails to illuminate or **BAT LOW** is shown on the display replace the batteries. There is room in the carrying case to keep an extra set of alkaline batteries.
3. During successful start-up the instrument will display:
 - a. Product name and model version
 - b. System check
 - c. Date and time
 - d. Gas Type
 - e. **CAL PAST DUE** when calibration is overdue
 - f. Warm-up countdown
 - g. **AUTOZERO** indicating the zeroing of the sensor
 - h. Working display

NOTE: If a sensor is completely inoperable or improperly zeroed at start up, the display will show **ERROR LEL** followed by **FAIL**.

4. Model 3.30 displays LEL% only. Model 3.35 displays LEL% and ppm. All LEL readings have a resolution of 0.1% LEL or 50ppm methane. All ppm readings have a resolution of 1ppm or 10ppm and are displayed simultaneously with the LEL display.
5. It may be necessary to manually zero the instrument based on company practices and environmental conditions.

⚠ CAUTION: Zeroing should be done in a gas free environment only.

6. When testing high areas or overhead lines the use of the optional extension adapter will allow a broom handle or painters stick to extend the instrument to the area where sensing must be accomplished. This slides onto the battery sleeve and is held in place by the locking nut assembly.
7. When a gas is sensed the display will update. Additionally, a series of LEDs on the front of the instrument will illuminate when the preset concentrations of the calibration gas are reached. If an alarm condition exists, based on a preset alarm point, the red (HAZ 3) LED will flash and the alarm will sound.

The preset levels of the LED warning lights are:

Amber LED/Low	5 - 9.9% LEL methane
Red LED/Haz1	10.0 - 24.9% LEL
Red LED/Haz2	25.0 - 49.9% LEL
Red LED/Haz3	50.0 - 100% LEL

⚠Caution: These instruments have cross sensitivities to a variety of gases.

8. During an alarm condition (factory default at 50% LEL) the display will flash, LED HAZ 3 will flash and an audible alarm will sound indicating a potentially unsafe environment. To disable the audible alarm press and release the mute button (A). To enable the alarm press and release it again.

9. To assist in locating the source of small combustible gas leaks or surveying areas outdoors or indoors, rotate the thumbwheel located on the right side of the instrument until a steady ticking sound is heard. Note: There is no warm-up for this feature as it uses the LEL sensor that is already operating. Move the sensor toward the area suspected of leakage. As the sensor moves closer to a leak source the tick will increase. When the tick becomes a steady tone rotate the thumbwheel in a clockwise direction while keeping the sensor in the same position. This will slow down the tick and allow the operator to find a higher concentration using the same procedure. If the tick goes away you have moved away from the leak or there is no more gas present. For best results always use the leak detector prior to using any liquid leak detection fluids as these sensors will detect their presence.

10. At any time the operator may save the readings on the display by pressing the SAVE/ZERO button (C). This will save all readings for download at a later time.

The memory is factory set to store 6 events. This can be adjusted from 1-15 at the factory. The most recent save is first during download.

11. Following Federal, State, Municipal and/or Company procedures move to the areas where gas readings are suspected or must be tested. During sampling the respective readings may change. Audible and visual alarms will activate when the preset limits are reached.

12. When being used in dark areas an automatic backlight will illuminate the display.

13. To turn instrument off, push and hold the power button (A) for 5-6 seconds until **POWER DOWN** appears on the display.

CALIBRATION CHECK

To verify the accuracy of any **Sensit® HXG-3**, it must be exposed to a known concentration of test gas. Any sensor that does not meet the specifications listed in this manual may require calibration or replacement. A calibration check does not update the calibration due date. Full calibration is required to update these times.

A calibration past due message will illuminate during warm-up if calibration has not been performed per your company specified interval. Anytime it is suspected the **Sensit® HXG-3** is not working properly, check calibration.

MENU

The **Sensit® HXG-3** has several features in the user menu. These include:

PRINT MENU: SESSION LOG - print data that was saved.

CAL LOG - print last 4 successful calibrations.

SMART CAL - access to Smart-Cal Calibration Station.

CALIBRATION: Calibrate LEL and access Smart-Cal Calibration Station.

POWER OFF: Set the automatic shut off timer in minutes.

SET CLOCK: Set date and time.

SHOW CAL LOG: Display last calibration.

SHOW SES LOG: Display saved gas reading data with date and time.

BUMP TEST: Perform automatic test for response to minimum of 80% of calibrated gas value within 30 seconds.

SMART-CAL: Access automatic calibration station.

GAS TYPE: Select natural/methane or pentane as primary gas to be sensed.

PRINT MENU

From the working display access the user menu by pressing and holding the MENU button (B) until the top line of the display reads **USER MENU**. The bottom line will read **PRINT MENU**. Press the MENU button (B) to access the print menu options. Use the SAVE/ZERO button (C) to select the **CAL LOG** or **SESSION LOG**.

At this time prepare the printer. Aim the IR window on the right side of the instrument to the IR receptor on the printer. Position the instrument 6-12" from the IR receptor and press the MENU button (B). Downloading will begin immediately. When the display no longer reads **PRINTING...** use the SAVE/ZERO button

MENU *continued from page 11*

(C) to scroll to another PRINT MENU function. Pressing the POWER/MUTE button (A) will reenter the **USER MENU**. Use the SAVE/ZERO button (C) at this time to scroll to another menu function. Pressing the POWER/MUTE button (A) will return the instrument to the working display.

CALIBRATION *(see page 16 for complete instructions)*

From the working display access the user menu by pressing and holding the MENU button (B) until the top line of the display reads **USER MENU**. Press and release the SAVE/ZERO button (C) until the bottom line displays **CALIBRATION**.

POWER OFF

From the working display access the menu by pressing and holding the MENU button (B) until the top line of the display reads **USER MENU**. Press and release the SAVE/ZERO button (C) until the bottom line displays **POWER OFF**. Press the MENU button (B). Use the SAVE/ZERO button (C) to increase the number of minutes of run time and the MENU button (B) to reduce them. Setting the timer to 0 will cause the unit to always remain on. After adjusting the number, press and release the left button (A) to save the adjustment. Use the SAVE/ZERO button (C) at this time to scroll to another menu function. Pressing the POWER/MUTE button (A) will return the instrument to the working display.

SET CLOCK

From the working display access the user menu by pressing and holding the MENU button (B) until the top line of the display reads **USER MENU**. Press and release the SAVE/ZERO button (C) until the bottom line displays **SET CLOCK**. Press the MENU button (B). The day will flash upon entering the **SET CLOCK**

option. The SAVE/ZERO button (C) advances to the next item are based on US time and date settings using a 24 hour clock. After adjusting all numbers press and release the POWER/MUTE button (A) to save the adjustment. Use the SAVE/ZERO button (C) at this time to scroll to another menu function in the USER MENU. Pressing the POWER/MUTE button (A) will return the instrument to the working display.

SHOW CAL LOG

From the working display access the user menu by pressing and holding the MENU button (B) until the top line of the display reads **USER MENU**. Press and release the SAVE/ZERO button (C) until the bottom line displays **SHOW CAL LOG**. Press the MENU button (B) and the display will show the last gas calibrated and calibration date. Pressing any button will return the display to the user menu. Pressing the POWER/MUTE button (A) will return the instrument to the working display.

SHOW SES LOG

From the working display access the user menu by pressing and holding the MENU button (B) until the top line of the display reads **USER MENU**. Press and release the SAVE/ZERO button (C) until the bottom line displays **SHOW SES LOG**. Press the MENU button (B). Use the SAVE/ZERO button (C) to scroll to the saved session you wish to review. **SESSION 1** is the most recent data saved. Pressing the MENU button (B) will display the date and time of that session. Pressing the MENU button (B) again will display the gas reading. Press the POWER/MUTE

(B) again will display the gas reading. Press the POWER/MUTE button (A) to return to **SESSION(#)** and pressing the SAVE/ZERO button (C) will allow you to scroll all previously saved **SESSIONS**. Pressing the POWER/MUTE button (A) 2 times will return you to the **USER MENU**. Pressing the POWER/MUTE button (A) once more returns you to the working display. The number of stored session log saves is factory set at 6. It can store up to 100 by changing a factory setting (contact SENSIT TECHNOLOGIES for instructions).

BUMP TEST

From the working display access the menu by pressing and holding the MENU button (B) until the top line of the display reads **USER MENU**. Press and release the SAVE/ZERO button (C) until the bottom line displays **BUMP TEST**. Prepare 50% LEL methane (or pentane) calibration gas for application to the instrument.

Apply calibration gas to the instrument sensor. Press the MENU button (B). The reading must read 80% of calibrated value within 30 seconds. The reading is on the left side and the timer is on the right side of the display.

If the instrument passes, the display will read **BUMP TEST PASSES**, a beep will sound and the unit display will automatically return to the user menu. If the instrument fails, the display will read **BUMP TEST FAILED** and a beep will sound. Repeated bump test failure indicates possible need for instrument repair. Contact J And N for instructions.

At the end of any bump test press the POWER/MUTE button (A) to return to the working display.

SMART-CAL (methane calibration only)

From the working display access the menu by pressing and holding the MENU button (B) until the top line of the display reads **USER MENU**. Press and release the SAVE/ZERO button (C) until the bottom line displays **SMART CAL**. Place the instrument into the cradle provided on the left side of the Smart-Cal Calibration Station. Attach the tubing from the station to the instrument sensor. Press the MENU button (B). The display will show **SMART CAL Communicating**. Select the test from the Smart-Cal Station to be performed. At the end of the test the instrument will beep 3 times and display **PASS** or **FAIL**. Retry the test if necessary by pressing the proper button on the Smart-Cal Station again. Press and release the POWER/MUTE button (A) to return the working display. Remove the tubing and return instrument to service or send instrument to the proper place for repair per company procedures.

SHORTCUT TO ACCESS SMART-CAL: Place the instrument into the cradle provided on the left side of the Smart-Cal calibration Station. Attach the tubing from the station to the instrument sensor. While in the working display press the POWER/MUTE button (A) for 2-3 seconds and release. The display will show **SMART CAL Communicating**. Perform all tests as described in the SMART CAL section.

GAS TYPE

From the working display access the user menu by pressing and holding the MENU button (B) until the top line of the display

reads **USER MENU**. Press and release the SAVE/ZERO BUTTON (C) until the bottom line displays **GAS TYPE**. Press the MENU BUTTON (B). Press Button (B) or Button (C) to change between PEN (Pentane) or NAT (Natural or Methane) as primary gas to be sensed. Press Button (A) to confirm selection is made.

CALIBRATION

Calibration is the process of setting the readings of the instrument to equal the value of certified calibration gases.

NOTE: Using calibration kits other than recommended by SENSIT TECHNOLOGIES may cause inaccurate readings. Repairs are required if any sensor fails to calibrate. Consult SENSIT TECHNOLOGIES for details.

NOTE: When calibrating, the numbers shown on the display represent the numbers seen by the microprocessor and should not be confused with actual gas readings.

Combustible Gas Calibration Procedure (50%LEL Methane or 50%LEL Pentane)

The calibration gas used for this procedure should match the Gas Type selected for your instrument. Refer to Gas Type in the Menu section of this manual. Instruments set to methane will calibrate with 50% LEL methane/air while those set to pentane will calibrate with 50% LEL pentane/air.

Prior to calibration allow the instrument to operate for 5 minutes in a gas free environment. Manually zero the instrument by

press and holding the (C) button until the display shows AUTOZERO. Prepare the corresponding calibration gas (methane or pentane), regulator and adapter.

From the working display access the USER MENU by pressing and holding the (B) button until the top line of the display reads USER MENU. Press and release the (C) button and the bottom line should read CALIBRATION. Press and release the (B) button, the top line will read CALIBRATION and the bottom line will read LEL 50%.

Apply the appropriate calibration gas for your instruments set-up and press the (B) button to start the automated calibration process.

If calibration is successful, the display will flash DATA SAVED before automatically returning to the calibration menu. Pressing the (A) button repeatedly will return the instrument to the working display. Remember to disconnect and shut off the gas supply.

If calibration is unsuccessful, the display will flash BAD CAL before returning to the calibration menu. In the event of a BAD CAL, remove the instrument from service and contact SENSIT Technologies for assistance.

NOTE: Calibration will be based on the last successful calibration. The calibration due date will not be updated until successful calibration has occurred. Any instrument that does not calibrate requires service. Contact SENSIT TECHNOLOGIES for details.

Your **Sensit® HXG-3** is warranted to be free from defects in materials and workmanship for a period of two years after purchase (excluding sensor, calibration and batteries). If within the warranty period, your instrument should become inoperative from such defects, the unit will be repaired or replaced at our option. This warranty covers normal use and does not cover damage which occurs in shipment or failure which results from alteration, tampering, accident, misuse, abuse, neglect or improper maintenance. Proof of purchase may be required before warranty is rendered. Units out of warranty will be repaired for a service charge. Internal repair or maintenance must be completed by a SENSIT TECHNOLOGIES authorized technician. Violation will void warranty. Units must be returned postpaid, insured and to the attention of the Service Dept. for warranty or repair.

This warranty gives you specific legal rights and you may have other rights which vary from state to state.