

# THERMOCOUPLE MINI-GRABBER ALLIGATOR CLIPS



## Standard Features

- Available In All ASTM Base Metal Thermocouple Types
- Allows Fast Simple Connections To Bare Thermocouple Wires
- Eliminates Multiple Cold End Junctions
- Thermocouple Material From The Tip To The Teeth
- Available With Convenient Coil Cords
- Recommended For Use With EDL's LT-100 Thermocouple Reference Instrument



# THERMOCOUPLE MINI-GRABBER ALLIGATOR CLIPS

Compensated Thermocouple Connector



Thermocouple Compensated Alligator Clips provide the perfect solution for making temperature measurements via terminal strips and screw head connections. These clips will not add an additional junction; they are thermocouple material from the tip back to the plug. They are available in all base metal thermocouple types and in uncompensated versions for other connections. The Alligator Clips can be purchased with coils cords and your choice of termination. All of the clips open a full 0.25" making them suitable for binding posts, screw heads or large diameter wire. Add confidence to your thermocouple measurements by using compensated leads. See our Thermocouple Mini-Grabbers for smaller wires and screws.



EDL Mini-Grabbers Alligator Clips are ordered by part #. The numbering system listed below is designed so you can easily identify the thermocouple type, lead type, lead length, and termination.

## Mini-Grabber Alligator Clips Part # Example

**MGA -** K - C - 1 - M

Mini-Grabber Alligator-TC Type - Lead Type - Lead Length - Termination

MGA	TC Type	Lead Type	Lead Length	Termination
MGA -	*E	C = Coil Cord	1 = 1'	M = Miniplug
	J	T = TFE/TFE	3 = 32"	J = Minijack
	K			L = Standard Plug
	T			U = Unterminated
	**N			
	CU			
	SET			

**Base Price:** \$81.00  
 Add: \$10.50 for L (Standard Plug)  
 Add: \$20.00 for a 32" Lead Length  
 \*\*Add: \$24.00 for TC Type N

\*E & N is available only in 1' lead length

## Standard Features

- Thermocouple Material From The Tip To The Teeth
- Wide Opening Jaw
- Available With Convenient Coil Cords
- Available In All ASTM Base Metal Thermocouple Types
- Allows Fast Simple Connections To Bare Thermocouple Wires
- Ideal For Connecting Thermocouple Wires Inside Process Connection Heads
- Recommended For Use With EDL's High Precision Thermocouple Reference Instrument — LT-100
- Eliminates Multiple Cold End Junctions
- Also Available In Copper/Copper

**Available Individually or as Base Metal Complete Set.**  
**Set Includes Types K, J, T, & E**  
**Part # MGA-SET-C-1-M**  
**\$324.00**

## Specifications

Part #	MGA
Length	3.3"
Width	0.5"
Jaw Width (At Tip)	0.218"
Maximum Opening	0.25"
Coil Cords	1 & 3 Feet

Your Electronic Development Labs, Inc. Distributor is:



The Temperature People® Since 1943  
 Electronic Development Labs, Inc.