

SANTRONICS

DC DETECTOR

Part #3315



OPERATING INSTRUCTIONS

1. Connect clip to system ground. Be certain a good ground is utilized.
2. Use tip to make contact with conductor wire or terminal test point.
3. If DC Voltage is present, the LED light in the white plastic tip will glow red. The BUZZER will also emit a loud buzzing sound.

ADVANTAGES

Buzzer - provides audio indication of DC voltage.

LED Light - will never burn out.

Large Clip - fits ground connection points small to large.

Sharp Tip - penetrates fine and heavy wire.

Construction - using the finest materials available.

Stainless Steel Tip - rust proof.

Solid State Circuitry - total reliability.

Test Lead Wire - 20 gauge heavy duty heat resistant.

Pen Sized - to fit comfortably in users hand. 100% Manufactured in the U.S.A.

APPLICATIONS

Automotive

Marine

Telecommunications

Industrial Controls

Aviation Trucks/RV's

Office Equipment

Heavy Equipment

Any other 6-50 Volt DC System

Farm Equipment

*Do Not Use On High Voltages, Or Primary Ignitions!
This Instrument Is Safe To Use On Computerized Vehicles!*

Visit our Web Site for Updates and Warranty Information

www.santronicsinc.com

SANTRONICS, INC.®

© Copyright Santronics 2011



To order parts and items, go to www.Instrumentation.com or call (800) 346-4620