

Part No.

DPPV-2FBA-RG

DPPV (+100 psi to -25" Hg) pump, 1/4" FBSPP gauge adapter, 1m hose, 1/4" FBSPP process conn.

Create pressure or vacuum and calibrate instrumentation using a pressure gauge or calibrator attached to the pump (gauge or calibrator not included)

Features

- Generate either 125 psi (8.6 bar) pressure or 23In Hg (584 mm Hg) vacuum with the same pump
- Unique design allows the user to convert from pressure to vacuum by simply twisting a knob, even with gloves on
- Two outlet ports allow connection to reference pressure gauge or pressure calibrator as well as device under test, thus eliminating a tee
- Large volume fine adjustment piston provides precise control, even at very low pressures
- Precisely vent pressure with soft seated bleed valve
- Made in U.S.A.

Item Includes

- Hand Pump - DPPV Assembly (DPPV)
- Gauge Adapter - G 1/4" female BSPP (ISO 228/1) x female Quick-test, no check-valve, brass (QTHA-2FBA-RG)
- Hose - Quick-test 6900 psi hose, brass hose ends, 1 m (3.3 ft) long (QTQT-HOS-1m)
- Hose Adapter - G 1/4" female BSPP (ISO 228/1) x male Quick-test, no check-valve, brass (QTHA-2FB0-RG)

Specifications

Pressure Range	0 to 125 psi (0 to 9 bar)
Vacuum Range	0 to 23"Hg (0 to 584 mmHG)
Media	Air
Outlet Port1	Male Quick-test outlet port, no check-valve, brass
Outlet Port2	Male Quick-test outlet port with cap and chain, brass
Temperature Range	0 to 130 °F (-18 to 54 °C)
Construction	Anodized Aluminum, Brass, Stainless Steel
Seal Materials	Buna-N, Delrin, Teflon
Fine Adjust Resolution	±0.01 psi
Weight	1.87 lb (0.8 kg)
Dimensions	H: 3.63 in (9.2202 cm) x W: 8.5 in (21.59 cm) x D: 3.63 in (9.2202 cm)



DPPV-2FBA-RG