

Part No.

MF2S-XF-XM-PL

*2 port Benchtop Manifold with Quick-test XT connections,
10,000 psi/350 bar, 316 Stainless Steel*

Ideal for testing multiple pressure instruments
at once up to 10,000 psi (700 bar).

Features

- Calibrate multiple pressure gauges, transmitters or transducers at once
- Vertically mounted ports are spaced far enough apart so larger gauges will fit easily
- Pressurize the system using a Ralston Quick-test XT hose
- Switch between pressure connections on devices under test without a wrench
- Quickly pressurize the system using a Ralston Quick-test hose
- Excellent for calibrating multiple pressure instruments in a thermal chamber
- Second side connection can be used to daisy-chain multiple manifolds together
- Made in USA



MF2S-XF-XM-PL

Specifications

Construction	Powder Coated Steel, Stainless Steel
Seal materials	Teflon, Viton