

Part No.

MF4S-XF-XM-PL

4 port manifold with Quick-test XT connections, 10,000 psi/350 bar, 316 Stainless Steel

Ideal for testing multiple pressure instruments at once up to 10,000 psi (700 bar).

Features

- Calibrate multiple pressure gauges, transmitters or transducers at once
- Vertically mounted ports are spaced far enough apart so larger gauges will fit easily
- Pressurize the system using a Ralston Quick-test XT hose
- Switch between pressure connections on devices under test without a wrench
- Quickly pressurize the system using a Ralston Quick-test hose
- Excellent for calibrating multiple pressure instruments in a thermal chamber
- Second side connection can be used to daisy-chain multiple manifolds together
- Made in USA



MF4S-XF-XM-PL

Specifications

Construction	Powder Coated Steel, Stainless Steel
Seal materials	Teflon, Viton