

Part No.

NPAK-0000-0-0

Nitropak only, no gauge adapter, no hoses, no process connections

Self contained unit provides a precise nitrogen source for calibrating differential and static pressure instrumentation using an external pressure calibrator

Features

- Proprietary pressure balanced fine adjustment piston allows for extremely precise, finger-tip control of pressure at 0.03 psi (2 mbar) or 3000 psi (210 bar) or any range in between.
- Easily refillable nitrogen cylinder holds enough gas for multiple calibrations
- Nylon bag to hold hose and fittings attached to inside of lid
- Includes storage compartment in control panel for pressure reference test gauge
- Low volume Quick-test hose, gauge adapter and process connection can be attached to NPAK without thread sealant or a wrench
- Designed to meet US Department of Transportation (DOT) and Canadian Transport Canada (TC) standards
- CE Approved for use in European Union - Designed to meet Pressure Equipment Directive (PED) and Transportable Pressure Equipment (TPED) standards
- Made in USA

Item Includes

- Assembly - NPAK Assembly (NPAK)

Specifications

Pressure Range	0 to 3000 psi (0 to 207 bar)
Vacuum Range	0 to 10"Hg (0 to 254 mmHG)
Temperature range	0 to 130 °F (-18 to 54 °C)
Construction	ABS Plastic, Aluminum, Anodized Aluminum, Brass, Plated Steel, Stainless Steel, Zippered Nylon with Velcro
Seal materials	Buna-N, Delrin, Teflon
Weight	28.8 lb (13.1 kg)
Dimensions	H: 18.5 in (46.99 cm) x W: 14.6 in (37.08 cm) x D: 7.5 in (19.05 cm)



NPAK-0000-0-0