

Part No.

# QSCM-5KPSIG-M

QSCM manifold, 5000 PSIG analog gauge, 20ft, 2ft hoses, (2) 1/4" MNPT process conn., nylon bag

Perform static pressure calibrations using nitrogen with included calibration manifold, pressure gauge and hoses

## Features

- Fine adjustment piston provides precise pressure control instead of trying to make adjustments with a pressure regulator and a needle valve
- Soft-seated valves make filling and venting the system very precise
- Compact design allows the manifold, gauge adapter and hoses to fit in the included nylon bag
- Low volume Quick-test hose, gauge adapter and process connection reduce gas usage and make nitrogen cylinders last longer
- Each kit comes with the 0.25% full scale accuracy reference test gauge, hoses and pressure gauge adapter needed so that you can start calibrating within minutes
- Made in U.S.A.

## Item Includes

- Assembly - QSCM Assembly (QSCM)
- Gauge - 0-5000 psig Analog Test Gauge ( $\pm 0.25\%$  full scale accuracy) (GAUG-5000)
- Gauge Adapter - 1/4" female NPT x female Quick-test, no check-valve, S.S. (QTHA-2FSA)
- Hose - Quick-test 6900 psi hose, S.S. hose ends, 20 ft (6.10 m) long (QSQS-HOS-20ft)
- Hose - Quick-test 6900 psi hose, S.S. hose ends, 2 ft (61 cm) long (QSQS-HOS-2ft)
- Hose Adapter - 1/4" male NPT x male Quick-test, no check-valve, S.S. (QTHA-2MS0)
- Hose Adapter - 1/4" male NPT x male Quick-test, no check-valve, S.S. (QTHA-2MS0)

## Specifications

Pressure Range	0 to 5000 psi (0 to 345 bar)
Gauge Pressure Range	0 to 5000 psig
Temperature range	0 to 130 °F (-18 to 54 °C)
Gauge Temperature range	-40 to 140 °F (-40 to 60 °C)
Construction	Stainless Steel
Seal materials	Buna-N, Delrin, Teflon
Weight	3.28 lb (1.5 kg)
Dimensions	H: 7.88 in (20.02 cm) x W: 5 in (12.70 cm) x D: 3.78 in (9.60 cm)



QSCM-5KPSIG-M