

Part No.

# QTHA-2FSA-AN-QD

*1/4" female 37 degree flare (AN/JIC) x female Quick-test, no check-valve, S.S.*

Connect a male 37° flare AN/JIC fitting to a Quick-test hose without a wrench

## Features

- A unique design allows connection to standard male 37° flare fitting using a pressure-assisted o-ring seal
- Pressure helps to seal the fitting better
- Stainless steel construction
- Made in USA



QTHA-2FSA-AN-QD

## Specifications

Pressure Range	0 to 5000 psi (0 to 345 bar)
End C1	1/4" Female JIC 37° Flare with Quick-Disconnect
End C2	Female Quick-test
Has Check Valve	No
Temperature range	0 to 225 °F (-18 to 107 °C)
Construction	Stainless Steel
Seal materials	Buna-N, Teflon
Dimensions A	1.94 in (4.93 cm)
Dimensions B	0.95 in (2.41 cm)