

Part No.

# QTHA-2FSA-QD

1/4" female NPT Quick-connect x female Quicktest, no check valve, S.S.

Connect Quick-test hoses to a male NPT pressure gauge. It allows one to connect a hose to a pressure gauge, calibrate it and remove it without a wrench or thread sealant.

## Features

- A unique design allows connection to any male NPT pressure gauge connection using a pressure-assisted o-ring seal
- Pressure helps to seal the fitting better
- Stainless steel construction
- Made in USA



QTHA-2FSA-QD

## Specifications

Pressure Range	0 to 5000 psi (0 to 345 bar)
End C1	1/4" Female NPT with Quick-Disconnect
End C2	Female Quick-test
Has Check Valve	No
Temperature range	0 to 225 °F (-18 to 107 °C)
Construction	Stainless Steel
Seal materials	Buna-N, Teflon
Dimensions A	1.94 in (4.93 cm)
Dimensions B	0.95 in (2.41 cm)