

Part No.

# QTHA-3TS0

*3/8" tube fitting x male Quick-test, no check-valve, S.S.*

Make a bubble-tight connection to any Swagelok, Parker, Hoke, SSP, Tylok or equivalent tube fitting without a wrench

## Features

- An excellent solution for connecting to tube fittings for pressure calibration, gas sampling, pressure reading and testing
- A unique design that seals on an o-ring to prevent damage to a tube fitting
- Make and remake hundreds of times without over-tightening a tube fitting
- Made in USA



QTHA-3TS0

## Specifications

Pressure Range	0 to 5000 psi (0 to 345 bar)
End C1	3/8" Tube Fitting
End C2	Male Quick-test
Has Check Valve	No
Temperature range	0 to 225 °F (-18 to 107 °C)
Construction	Stainless Steel
Seal materials	Buna-N
Dimensions A	1.53 in (3.89 cm)
Dimensions B	0.72 in (1.83 cm)