

Part No.

# QTHA-4FS0-QD

*1/2" female NPT Quick-connect x male Quick-test, no check-valve, S.S.*

Connect Quick-test hoses to a male NPT pressure gauge. It allows one to connect a hose to a pressure gauge, calibrate it and remove it without a wrench or thread sealant.

## Features

- A unique design allows connection to any male NPT pressure gauge connection using a pressure-assisted o-ring seal
- Pressure helps to seal the fitting better
- Stainless steel construction
- Made in USA



QTHA-4FS0-QD

## Specifications

Pressure Range	0 to 5000 psi (0 to 345 bar)
End C1	1/2" Female NPT
End C2	Male Quick-test
Has Check Valve	No
Temperature range	0 to 225 °F (-18 to 107 °C)
Construction	Stainless Steel
Seal materials	Buna-N, Teflon
Dimensions A	1.69 in (4.29 cm)
Dimensions B	1.39 in (3.53 cm)