

Part No.

# QTHA-4TB0

*1/2" tube fitting x male Quick-test, no check-valve, brass*

Make a bubble-tight connection to any Swagelok, Parker, Hoke, SSP, Tylok or equivalent tube fitting without a wrench

## Features

- An excellent solution for connecting to tube fittings for pressure calibration, gas sampling, pressure reading and testing
- A unique design that seals on an o-ring to prevent damage to a tube fitting
- Make and remake hundreds of times without over-tightening a tube fitting
- Made in USA



QTHA-4TB0

## Specifications

Pressure Range	0 to 5000 psi (0 to 345 bar)
End C1	1/2" Tube Fitting
End C2	Male Quick-test
Has Check Valve	No
Maximum Working Temperature	225 °F (107 °C)
Construction	Brass
Seal materials	Buna-N
Dimensions A	1.7 in (4.32 cm)
Dimensions B	1 in (2.54 cm)