

Part No.

# QTHA-FRS0

*Rosemount 5/16"-24 UNF x male Quick-test, no check-valve, S.S.*

Connect a Quick-test hose directly to a DP transmitter using the bleeder port when the transmitter is not mounted on a 3 or 5 valve manifold or when the manifold is not easily accessible.

## Features

- This unique fitting makes a metal to metal seat on the transmitter and a Quick-test hose can be attached on the other side
- Connects where the bleeder screw goes into a DP transmitter
- Made in USA



QTHA-FRS0

## Specifications

Pressure Range	0 to 5000 psi (0 to 345 bar)
End C1	5/16-24 DP Transmitter
End C2	Male Quick-test
Has Check Valve	No
Temperature range	0 to 225 °F (-18 to 107 °C)
Construction	Stainless Steel
Seal materials	Buna-N
Dimensions A	2.16 in (5.49 cm)
Dimensions B	0.56 in (1.42 cm)