

Part No.

QTVF-000B-2F-2F

Shut-off valve - 1/4" Female NPT x 1/4" Female NPT with male QT test port, brass

Install between a pressure gauge and the process and isolate the process from the gauge to perform a calibration of the gauge. After completing the calibration open the valve and place the gauge on-line, all without blowing down the system.

Features

- * Use whenever there is a gauge that needs frequent calibration or verification



QTVF-000B-2F-2F

Specifications

Pressure Range	0 to 3000 psi (0 to 207 bar)
End C1	1/4" Female NPT
End C2	1/4" Female NPT
End C3	Male Quick-test with Cap and Chain
Has Block Valve	Yes
Has Vent Valve	No
Temperature range	0 to 225 °F (-18 to 107 °C)
Construction	Brass
Seal materials	Buna-N, Delrin, Teflon
Dimensions A	3.57 in (9.07 cm)
Dimensions B	2.31 in (5.87 cm)