

Part No.

QTVF-000S

Shut-off valve - 1/4" MNPT x 1/4" FNPT with male QT test port,
S.S.

Install between a pressure gauge and the process and isolate the process from the gauge to perform a calibration of the gauge. After completing the calibration open the valve and place the gauge on-line, all without blowing down the system.

Features

- * Use whenever there is a gauge that needs frequent calibration or verification



QTVF-000S

Specifications

Pressure Range	0 to 3000 psi (0 to 207 bar)
End C1	1/4" Male NPT
End C2	1/4" Female NPT
End C3	Male Quick-test with Cap and Chain
Has Block Valve	Yes
Has Vent Valve	Yes
Maximum Working Temperature	225 °F (107 °C)
Construction	Stainless Steel
Seal materials	Buna-N, Delrin, Teflon
Dimensions A	2.6 in (6.60 cm)
Dimensions B	2.5 in (6.35 cm)