

Part No.

SPOV-100PSIG-D

Gas Sampling Pump, 2 hoses, 100 psi digital gauge kit

The SPOV gas sampling pump can pull low pressure gas from a well and boost it to 25 psi to pump it into a sample cylinder

Features

- Hard Anodized aluminum body and stainless steel fittings so no issues with corrosion, cracking or cross contamination of the sample
- Inlet and outlet hose has Nylon inner core tube which does not affect the sample
- Low compression rate will not adversely affect the sample by bringing the gas close to the hydrocarbon dew point (25 psi/2 bar)
- Hydrocarbon-free lubricant does not contaminate the sample with any foreign hydrocarbons
- Designed in accordance with API MPMS Chapter 14.1 on natural gas sampling
- Made in USA



SPOV-100PSIG-D

Specifications

Pressure Range	0 to 100 psi (0 to 7 bar)
Construction	Anodized Aluminum, Stainless Steel
Seal materials	Viton
Weight	0.1 lb (0.1 kg)
Dimensions	H: 7.88 in (20.0152 cm) x W: 3.75 in (9.525 cm) x D: 7.75 in (19.685 cm)