

Part No.

SP0V-1MSA-6-3

Gas Sampling Pump, 2 hoses, 1/4" Male NPT gauge connection

The SP0V gas sampling pump can pull low pressure gas from a well and boost it to 25 psi to pump it into a sample cylinder

Features

- Hard Anodized aluminum body and stainless steel fittings so no issues with corrosion, cracking or cross contamination of the sample
- Inlet and outlet hose has Nylon inner core tube which does not affect the sample
- Low compression rate will not adversely affect the sample by bringing the gas close to the hydrocarbon dew point (25 psi/2 bar)
- Hydrocarbon-free lubricant does not contaminate the sample with any foreign hydrocarbons
- Designed in accordance with API MPMS Chapter 14.1 on natural gas sampling
- Made in USA



SP0V-1MSA-6-3

Specifications

Pressure Range	0 to 100 psi (0 to 7 bar)
Construction	Anodized Aluminum, Stainless Steel
Seal materials	Viton
Weight	0.1 lb (0.0 kg)
Dimensions	H: 4.75 in (12.065 cm) x W: 3.75 in (9.525 cm) x D: 7.75 in (19.685 cm)