

Part No.

XTHA-2FSA

1/4" female NPT x female Quick-test XT, stainless steel

Connect Male NPT pressure gauge or other Male NPT device to a Ralston hand pump or nitrogen calibration device to create one side of a quick-disconnect to 10,000 psi

Features

- Install with thread tape once onto any male NPT pressure gauge then use the Quick-test connection to quickly connect or disconnect from any Ralston hand pump, nitrogen calibration device or other Quick-test adapter
- Saves the threads on a pressure gauge by not needing to make and remake the connection with thread sealant
- Note that these are not compatible with QT or QS hoses. Please use Quick-test XT hoses
- Made in USA



XTHA-2FSA

Specifications

Pressure Range	0 to 10000 psi (0 to 689 bar)
End C1	1/4" Female NPT
End C2	Female Quick-test XT
Has Check Valve	No
Temperature range	0 to 225 °F (-18 to 107 °C)
Construction	Stainless Steel
Dimensions A	1.52 in (3.86 cm)
Dimensions B	0.75 in (1.91 cm)