

## Hydraulic Hand Pumps

Simple, fast field testing for connecting a calibrator to a process connection. Connect this directly between the equipment to be tested and a reference. No need for a "T" joint.

### Features

- Portable hand operated hydraulic pumps that easily generate up to 5000 psi (350 bar)
- Two outlet ports allow user to connect to both device under test and external pressure calibrator thus eliminating a tee.
- Fine Adjustment piston provides an easy way to achieve precise pressure
- Vent valve is both durable and precise
- Liquid reservoir holds enough fluid for multiple calibrations
- Low volume Quick-test hose, gauge adapter and process connection can be attached to pump without thread sealant or a wrench
- Rugged, all metal construction improves temperature and pressure stability
- Made in U.S.A.



Hydraulic Hand Pumps

### Select a model for more information

Model	Pressure Range	Port 1	Port 2	Hose Included	Hose Adapter
<a href="#">HP0V-0000</a>	0 - 3000 PSI	Male Quick-test outlet port with check valve, brass	None	3 ft	1/4" Male NPT
<a href="#">XH0V-0000</a>	0 - 5000 PSI	Male Quick-test outlet port with cap and chain, brass	None	3 ft	1/4" Male NPT