

# User Manual JOFRA STS-050 A Probes 250/350



## User manual JOFRA STS-050 A

#### Probes 250/350

© Copyright 2006 AMETEK Denmark A/S



1.0	General information3					
2.0	Safe	Safety Instructions4				
3.0	Introduction5					
4.0	Fun	6				
	4.1	Functional description	6			
	4.2	Connections	6			
	4.3	Serial number	8			
5.0	Оре	9				
	5.1	Operation area	9			
6.0	Mai	Maintenance10				
7.0	Technical specifications11					

#### 1.0 General information

This manual is only effective for the following products:

JOFRA STS-050 A - 250 mm

JOFRA STS-050 A - 350 mm

The products are manufactured by:



#### AMETEK Denmark A/S

Gydevang 32-34 3450 Allerød - Denmark

> TEL: +45 48 16 80 00 FAX: +45 48 16 80 80

#### 2.0 Safety Instructions



# Read this manual carefully before using the sensor!

In order to avoid any personal injuries and/or damage to the sensor all safety instructions and warnings must be observed.



#### Warning

- Do not use in hazardous area.
- Handle carefully.
- Never exceed temperature range



#### Caution...

- The probe must **always** be protected against any mechanical damage.
- The probe must **never** be exposed to mechanical shock effects.
- Avoid thermal shock
- Any bending of the probe may cause permanent damage
- **Never** use force or tools to place the probe.

## 3.0 Introduction

The JOFRA STS-050 A probes are designed for fast and traceable calibration and temperature measuring with AMETEK DTI050, and are ready for use.

Please read this manual carefully before use, to obtain maximum value of your calibration system.



#### Warning

- Read this manual before use.
- Do not use in hazardous area.
- Handle carefully.
- Never exceed temperature range

#### 4.0 Functionality

#### 4.1 Functional description

The probe can be used for measuring temperature in the range-50°C to 400°C (-58°F to 752°F).

The JOFRA STS-050 A probes may be supplied with certificates for a limited temperature range.

The resistance of the JOFRA STS-050 A probe is converted to temperature according to IEC-751 (ITS-90) (calculated coefficients specific for the probe is stated on the certificate).

#### 4.2 Connections

The probe is delivered with a connecting cable. The figures on the next page are shown from the connector side of the probe connector : The pin-layout is as follows:

Cable 128977 & 129090




Pin 1 : RTD I-Pin 2 : RTD S-Pin 3 : RTD S+ Pin 4 : RTD I+ Pin 5 : Memory GND Pin 6 : Memory I/O

Cable 128976




Pin 1 : RTD I+ Pin 2 : RTD S+ Pin 3 : RTD S-Pin 4 : RTD I-

#### Cable 128975



#### 4.3 Serial number

The serial number is placed on the handle as shown on the figure below:



#### 5.0 Operation

#### 5.1 Operation area

All the probes are intended for use in areas which meet the following:

Ambient temperature

range	:	-20°C to 70°C (-4°F to 158°F)
Humidity	:	0% to 90%

Protection class : IP 50



#### Warning

Do not use in hazardous areas.

#### 6.0 Maintenance

The probe does not require specific maintenance before or after use. The user may carry out the following procedure himself:

• Cleaning the probe : Use alcohol or water and a soft cloth.



#### Caution...

- The probe must always be protected against any mechanical damage.
- The probe must never be exposed to mechanical shock effects.
- Avoid thermal shock
- Any bending of the probe may cause permanent damage

## 7.0 Technical specifications

Probe specifications:

Sensor type		Platinum sensor Pt100. $\alpha = 0.00385$
Probe length		250 mm (9.8 in) 350 mm (13.8 in)
Temperature range		-50°C to 400°C (-58°F to 752°F)
Accuracy		
Repeatability	:	0.005°C (0.009°F)
Hysteresis <sup>1)</sup>	:	0.01°C @ 0°C (0.02°F@32°C)
Stability <sup>2)</sup>	:	typ. 0.014°C @ 0°C (0.025°F@32°F)
Self heating effect		0.06°C/mW / 0.108°F/mW
Diameter		OD4 mm
Immersion depth		100 mm (3.94 in)
Media compatibility		INCONEL 600

1)When used in the range  $-50^{\circ}$ C to  $400^{\circ}$ C (-58°F to 752°F) 2)Stability when exposed to  $400^{\circ}$ C (752°F) for 100 hours. Stability will depend on actual use of the probe.

Response time	:	$\tau(50\%) = 8$ sec.
		$\tau(90\%) = 26 \text{ sec.}$
Recommended		
meas. current	:	1 mA
Connection	:	Redel plug with build in memory is standard

Certificate:

All probes are supplied with a traceable certificate according to the ITS 90 temperature scale. The probes are as standard calibrated in the range  $-45^{\circ}$ C to 400°C (-49°F to 752°F).

Calibration is carried out at:

- -45°C/-49°F
- -20°C/-4°F
- 0°C/32°F
- 100°C/212°F
- 250°C/482°F
- 400°C/752°F



#### AMETEK

Test & Calibration Instruments One of the world's leading manufacturers and developers of calibration instruments for temperature, pressure and process signals as well as for temperature sensors both from a commercial and a technological point of view.



United Kingdom Tel +44 (0)1243 833 302 stc.uk@ametek.com

France Tel +33 (0)1 30 68 89 40 general.lloyd-instruments@ametek.fr

Germany Tel +49 (0)2159 9136 510 info.mct-de@ametek.de

Denmark Tel +45 4816 8000 jofra@ametek.com USA Florida Tel +1 (800) 527 9999 cal.info@ametek.com

California Tel +1 (800) 444 1850 crystal@ametek.com

India Tel +91 22 2836 4750 jofra@ametek.com

#### www.ametekcalibration.com

Singapore Tel +65 6484 2388 jofra@ametek.com

China Shanghai Tel +86 21 5868 5111

Beijing Tel +86 10 8526 2111 jofra-china.sales@ametek.com.cn

Information in this document is subject to change without notice. @2015 by AMETEK, Inc., www.ametek.com. All rights reserved.